

# TopoDroid Calibration Settings

Marco Corvi

[marco.corvi@gmail.com](mailto:marco.corvi@gmail.com)

2017

# Calibration settings (1)

- Group policy
  - Four at a time [default]
  - Groups of four only for the first 16
  - Distance
- Grouping distance tolerance
- Calibration algorithm exit error
- Calibration algorithm maximum number of iterations

# Calibration settings (2)

- Raw data display
  - None
  - Decimal
  - Hexadecimal
- Algorithm choice
  - Auto
  - Linear
  - Non-linear

# Calibration settings (3)

- Min-algo settings
  - Alpha: adjustment factor
  - Beta: weight of magnetic dip
  - Gamma: weight of X components of G and M
  - Delta: weight of X component of  $G^M$