

Calibration export

To export a calibration TopoDroid must be at level advanced, or above. From the settings dialog of the main window set the level to advanced (fig. 1).

Next go to the device window, and open the calibration list dialog (fig. 2).

Tap the calibration to export, to open the calibration info window.

The first menu of this window is the "Export" menu (fig. 3).

Tapping it opens the export dialog (fig. 4). There is only one export format, namely "csv" (comma separated values). Tap the button "Save" to export the calibration.

The exported file is in the folder "ccsv" of TopoDroid.

